

Transputer Link Adapter Board

User Guide

Gnome Computers Ltd
25A Huntingdon St.
St. Neots
Cambridgeshire
PE19 1BG

Tel. (0480) 406164

Issue 2

2

Introduction

The Transputer Link Adapter Board (TLAB) is a circuit card which plugs into the expansion bus of the Acorn Archimedes computer. Expansion cards for the Archimedes are called podules and the TLAB is a so-called Simple Podule. Its function is to allow the Archimedes to access data sent over Inmos transputer links. This is achieved with the use of an Inmos link adapter chip on the TLAB. This chip has a register interface which is mapped into the Archimedes' I/O address space and an Inmos link interface which is available on a connector on the card. Data written to the chip from the Archimedes may be sent down the link while data received from the link may be read by the Archimedes.

The TLAB can also be programmed to interrupt the Archimedes when the link is ready to send more data and/or when data has been received from the link. It also contains a control/status register which is used to configure the card and control various lines which appear on the link interface on the card.

Installation

The TLAB card is a single Eurocard PCB measuring 100x160mm. It has a 64 way connector at one end and a 12 way connector and mounting panel at the other end. The card contains static sensitive ICs and so appropriate precautions should be taken while handling and installing it.

The card is installed by plugging it into a free slot in the expansion backplane. There is no need to configure the card to respond to a particular address as each slot has a distinct address range. The driving software will normally scan all the slots to locate the appropriate podule.

The machine should be switched off while the installation is done. The lid of the machine should be removed and the board plugged into a free slot in the podule backplane. The rear panel can then be screwed down to secure the card in the machine. Note that a design feature of the Archimedes means that podules designed to the Eurocard format will protrude from the rear of the machine by approximately 2.5mm. Finally, the lid should be replaced and the installation is then complete.

The TLAB draws power from the +5V rail of the Archimedes and requires approximately 150mA.

Link connections

The link connection is made via a 12 way connector which protrudes through the TLAB mounting panel. The connector is formed from two 5 pin Molex connectors with locking mechanisms. There is a 0.2" gap between the two connectors and one connector has a pin removed so that there are only 9 pins actually present. The pins are numbered from the left when viewed from the rear of the machine as follows:

<u>Pin</u>	<u>Signal</u>	<u>Function</u>
1	GND	Connected to Archimedes' 0V rail
2		(absent)
3	LinkOut	Link data out of TLAB
4	LinkIn	Link data into TLAB
5	GND	
6		(absent)
7		(absent)
8	ResetOut	Reset line to transputer
9	AnalyseOut	Analyse line to transputer
10	ErrorIn	Error line from transputer
11	GND	
12	GND	

All the outputs are driven by a 74HCT244 driver chip. The LinkOut line has a 100 Ω ohm series resistor, the others are driven directly. The inputs are buffered by the same 74HCT244. The LinkIn line has a 10K Ω pulldown resistor and the ErrorIn line has a 100K Ω pulldown.

In order to conform to the Inmos standard it is necessary to cut off pins 11 and 12. The board is normally supplied with these pins intact so that a ground connection is available where the application requires it.

Programming the TLAB

It is assumed that the reader is familiar with the Acorn documentation for podules ("A Series Podules", Acorn Computers, May 1987) and the Inmos data sheet for the IMSC012 link adapter chip. All devices on the TLAB are byte wide and should therefore be accessed with byte (as opposed to word) cycles.

The TLAB contains a podule identity (PI) ROM which is mapped into the PI space. The ROM contains an extended (8 byte) PI as follows:

<u>Byte</u>	<u>Content</u>	<u>Comment</u>
0	X'00'	(X'01' if generating IRQ)
1		(reserved)
2		(reserved)
3	X'24'	Product type (low)
4	X'00'	Product type (high)
5	X'0E'	Manufacturer (low)
6	X'00'	Manufacturer (high)
7	X'00'	Country

Bit 0 of byte 0 is a 1 when the TLAB is generating an IRQ interrupt. The TLAB does not generate FIQ interrupts.

The TLAB is a Simple Podule and is thus accessed by cycles controlled by the Archimedes' I/O controller chip. All devices on the TLAB may be accessed using fast cycles. In addition to the podule ID ROM the TLAB contains an Inmos C012 (or equivalent C011) link adapter chip and a control/status register (CSR). The four registers of the link adapter are mapped into successive words in the I/O space and the CSR is mapped into the next word. Thus, if the TLAB is placed in podule slot 0 in the Archimedes the memory map is as follows:

<u>Address</u>	<u>Content</u>	<u>Access speed</u>
X'33C0000'	PI byte 0	synchronous
X'33C0004'	PI byte 1	"
...	...	"
X'33C001C'	PI byte 7	"
X'3342000'	C012 reg 0	fast
X'3342004'	C012 reg 1	"
X'3342008'	C012 reg 2	"
X'334200C'	C012 reg 3	"
X'3342010'	CSR	"

This set of registers repeats at 8 word intervals throughout the podule address space. To maintain compatability with future products of a similar type, only

the lowest set of addresses should be used.

The control status register contains 4 bits which may be read or written and one bit which is read-only. The read/write bits are cleared to zero when the Archimedes' reset line is asserted. When writing to the CSR, the unused bits (4 to 7) should be zero to maintain compatibility with other similar products.

The functions of the bits in this register are as follows

Bit 0 - ResetOut. Writing a 1 asserts (drives low) the reset line on the link connector.

Bit 1 - AnalyseOut. Writing a 1 asserts (drives low) the analyse line on the link connector.

Bit 2 - LinkSpeed. Connected to the LinkSpeed pin of the link adapter chip. Writing a 1 causes the link adapter chip to operate with a 20MHz link speed. A zero causes a link speed of 10MHz.

Bit 3 - ChipReset. Writing a 1 asserts the reset line of the link adapter chip. Normally asserted with ResetOut and may be useful if the chip locks up because of a faulty link connection.

Bit 4 - ErrorIn. Reflects the state of the ErrorIn signal on the link connector. This bit is read-only and a 0 indicates the presence of an error (or absence of a link cable!).

The two interrupt signals of the link adapter chip are ORed together to generate the IRQ signal required by the Archimedes. The link adapter chip is reset whenever the Archimedes' reset line is asserted, thus ensuring that interrupts are disabled when the system starts up.